
http://www.hdx.ru

HDX


PARTS CATALOGUE




目录
CONTENTS

控制系统 — — —

零部件名称:	控制系统
PARTS NAME:	CONTROL




SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-00000007	变档手柄	HANDLE, GEAR SHIFT	1					
2	F4-02010000-A	变档拨叉组件	SHAFT, GEAR SHIFT	1					
3	JISB2401-P9	"O"形密封圈P9	O-RING P9	2					
4	GB/T820-M5x20	十字半沉头螺钉M5x20	PAN HEAD SCREW M5x20	1					
5	F4-02000003	变档弹簧	SPRING, GEAR SHIFT	1					
6	GB/T308-8	钢珠8	BALL 8	1					
7	GB/T5783-M5x25	六角螺栓M5x25	HEXAGON BOLT M5x25	1					
8	GB/T91-1.6x12	开口销1.6x12	COTTER PIN 1.6x12	1					
9	GB/T97.1-5	平垫圈5	PLAIN WASHER 5	2					
10	F4-02000006	变档连杆支架	LEVER, SHIFT ROD	1					
11	F4-02000004	变档连杆	SHIFT ROD	1					
12	F4-00000003	变档连杆连接器A	CONNECTOR, SHIFT ROD A	1					
13	F4-00000004	变档连杆连接器B	CONNECTOR, SHIFT ROD B	1					
14	F4-00000005	大垫圈	BIG, WASHER	1					
15	GB/T5783-M6x20	六角螺栓M6x20	HEXAGON BOLT M6x20	1					


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
42

零部件名称: 托架

PARTS NAME: BRACKET

SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-02000008	减震圈衬管	LINER, SHOCK ABSORPTION	4					
2	F4-02000007	上减震圈	UPPER BUSHING, SHOCK ABSORPTION	1					
3	F4-02020000	水上装置锁紧圈组件	UPPER LOCKING RING ASSY	1					
4	F4-01050000	角度调整杆组件	TILT ROD ASSY	1					
5	GB/T889.1-M8	非金属嵌件六角锁紧螺母M8	NUT, METALLOID EMBEDED HEXAGON M8	1					
6	F4-01000002	双孔固定板	PLATE, SPECTACLE	1					
7	F4-01020000	夹紧托架（左）组件	BRACKET LEFT ASSY	1					
8	F4-08000018	标贴18	STICKER 18	1					
9	F4-01030001	旋转支架座	BRACKET, SWIVEL	1					
10	GB/T6170-M6	六角螺母M6	HEXAGON NUT M6	1					
11	GB/T97.1-6	平垫圈6	WASHER PALTE 6	11					
12	F4-01000003	尼龙垫圈	WASHER, NYLON	2					
13	F4-01030103	手柄套	SHEATH HANDLE	1					
14	F4-01030003	支撑架扭簧（左）	TWIST SPRING, RETAINER BRACKET(LEFT)	1					
15	F4-01030002	支撑架尼龙衬套	BUSHING, NYLON	2					
16	GB/T5783-M6x20	六角头螺栓 M6x20	HEXAGON BOLT M6x20	2					
17	F4-01030005	支撑架固定盖	FIXED COVER , RETAINER BRACKET	1					
18	F4-01030100	角度定位支撑架组件	BRACKET ASSY, TILT LOCK	1					
19	F4-01030004	支撑架扭簧（右）	TWIST SPRING, RETAINER BRACKET(RIGHT)	1					
20	F4-01000006	锁紧钩扭簧（左）	TWIST SPRING, LOCKING (LEFT)	1					
21	F4-01000007	锁紧钩扭簧（右）	TWIST SPRING, LOCKING (RIGHT)	1					
22	GB/T5783-M6X12	六角头螺栓 M6x12	HEXAGON BOLT M6x12	2					
23	F4-01070000	起翘锁紧钩组件	TILT LOCKED CLASP ASSY	1					
24	F4-02000009	下减震圈	BOTTOM BUSHING, SHOCK ABSORBTION	1					
25	F4-01000004	螺栓垫管	BUSHER, BOLT	1					
26	F4-01010005	艉板夹紧手柄铆钉	RIVET, CLAMP HANDLE	2					
27	F4-01010004	艉板夹紧手柄	CLAMP HANDLE, TRANSOM	2					
28	F4-01010002	艉板夹紧螺杆	CLAMP BOLT, TRANSOM	2					
29	F4-01010003	艉板夹紧圆盘	CLAMP PLATE, TRANSOM	2					
30	GB/T5782-M6x125	六角螺栓 M6x125	HEXAGON BOLT M6x125	1					
31	GB/T5782-M8x135	六角螺栓 M8x135	HEXAGON BOLT M8x135	1					
32	F4-01010000	夹紧托架（右）组件	BRACKET RIGHT ASSY	1					
33	F4-01000005	旋转支架座盖	COVER, SWIVEL BRACKET	1					
34	GB/T5782-M6x35	六角头螺栓 M6x35	HEXAGON BOLT M6x35	6					
35	F4-01060002	锁紧手柄	CLAMP HANDLE	1					
36	GB/T875-4x11	扁平头半空心铆钉φ4x11	RIVET φ4x11	1					
37	F4-01060001	锁紧螺杆	LOCKED BOLT	1					
38	F4-01060000	锁紧手柄组件	LOCKED HANDLE ASSY	1					
39	GB/T96-6	大垫圈 6	BIG WASHER 6	2					



9
8
7
6
5
4
3
4
2
1
26
25
11
12
13
10
24
14
15
16
23
22
21
18
20
17
27
19

零部件名称: 操舵系统

PARTS NAME: STEERING


SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-01090001	操舵手柄	HANDLE, STEERING	1					
2	F4-01000009	操舵手柄衬套A	BUSHING, HANDTE STEERING A	1					
3	F4-01000012	手柄衬套波形垫圈	SPRING WASHER	1					
4	F4-01000010	衬套垫圈B	WASHER, BUSHING B	2					
5	F4-05000014	操舵手柄减震器	BUSHING, RABBER	1					
6	F4-01000011	衬套垫圈A	WASHER BUSHING A	1					
7	F4-01000008	操舵手柄衬套B	BUSHING, HANDLE STEERING B	1					
8	F4-01000014	操舵手柄盖板	COVER, HANDLE STEERING	1					
9	GB/T5783-M8x25	六角头螺栓 M8x25	HEXAGON BOLT M8x25	1					
10	F4-08000014	标贴14	STICKER 14	1					
11	GB/T91-1.6x12	开口销φ1.6x12	COTTER PIN φ1.6x12	1					
12	F4-01090200	阻力调整旋钮组件	BOLT, FRICTION ADJUSTING	1					
13	F4-08000012	标贴12	STICKER 12	1					
14	F4-01090006	衬套	BUSHING	1					
15	F4-01090007	压缩弹簧	SPRING, COMPRESSION	1					
16	GB/T848-10	小垫圈10	SMALL PLAIN WASHER 10	1					
17	GB/T820-M5x25	十字槽半沉头螺钉 M5x25	PAN HEAD SCREW M5x25	1					
18	F4-01090300	操舵手柄组件	STEERING HANDLE ASSY	1					
19	F4-01090003	操舵手柄握把摩擦块	FRICTION BLOCK	1					
20	F4-01090100	节气门杆组件	LEVER, THROTLLE	1					
21	GB/T818-M5x12	十字槽盘头螺钉 M5x12	PAN HEAD SCREW M5x12	2					
22	F4-01090002	节气门杆固定板	MOUNTED PLATE, THROTTLE	1					
23	F4-08000015	标志牌15	STICKER 15	1					
24	F4-01090008	油门钢索组件	THROTTLE CABLE ASSY	1					
25	F4-01090401	引擎停止安全索	STOPER, HANG ROPE ASSY	1					
26	F4-01090400	急停开关组件	ENGINE STOP SWITCH ASSY	1					
27	F4-01090004	尼龙垫圈	WASHER, NYLON	1					

零部件名称:	水上装置壳体
PARTS NAME:	UPPER CASING



SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-00000006	发动机密封垫	GASKET , ENGINE	1					
2	F4-00000001	空心定位销	HOLLOW PIN	4					S: 2件
3	GB/T97.1-6	平垫圈6	PLAIN WASHER 6	7					
4	GB/T5783-M6X35	六角头螺栓 M6x35	HEXAGON BOLT M6x35	7					
5	JB/T7940.1-M6	直通式压注油杯M6	GREASE CUP, DIRECT INFUSE M6	1					
6	F4-02000100	水上装置壳体组件	UPPER CASING ASSY	1					
7	F4-02000011	变档轴密封圈	WASHER, SHIFT ROD	1					
8	F4-02000012	水上装置橡胶堵头	RUBBER PLUG, UPPER CASING	2					
9	GB/T893.1-22	孔用弹性挡圈22	CIRCLIP 22	1					L
10	F4-02030003	驱动轴衬套橡胶套	RUBBER BUSHING, DRIVE	1					L
11	F4-02030002	驱动轴衬套	BUSHER, DRIVE SHAFT	1					L
12	F4-02030001	接长体	EXTENSION ASSY	1					L
13	F4-02000002	水上装置壳体铜套	COPPER SHEATHING, UPPER CASING	1					

零部件名称:	水下驱动组件
PARTS NAME:	LOWER DRIVE ASSY




SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	GB/T5782-M6x45	六角头螺栓 M6x45	HEXAGON BOLT M6x45	4					
2	F4-03000020	泵壳固定板	FIXED PLATE,WATER PUMP	2					
3	F4-03000021	泵壳橡胶管	RUBBER TUBE,WATER PUMP	1					

零部件名称: 水下驱动组件

PARTS NAME: LOWER DRIVE ASSY


SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
4	F4-03000013	水泵座定位销	PIN, WATER PUMP	2					
5	F4-03000019	水泵壳	HOUSING, WATER PUMP	1					
6	F4-03000018	泵壳密封垫	GASKET, WATER PUMP COVER	1					
7	F4-03000017	水泵内壳	INNER COVER, WATER PUMP	1					
8	F4-03060000	水泵叶轮	IMPELLER , WATER PUMP	1					
9	F4-03000015	外挡板	GUIDE PLATE, WATER PUMP	1					
10	F2.6-03000009	O形密封圈	O-RING	1					
11	F4-03020000L	变档凸轮组件(L)	CAM ASSY , SHIFT ROD(L)	1					L
	F4-03020000S	变档凸轮组件(S)	CAM ASSY , SHIFT ROD(S)	1					S
12	GB/T5783-M6x25	六角头螺栓M6×25	HEXAGON BOLT M6×25	1					
13	GB/T97.1-6	平垫圈6	PLAIN WASHER 6	5					
14	F4-03000012	水泵座	BASE , WATER PUMP	1					
15	F4-03000011	水泵座密封垫	GASKET, WATER PUMP BASE	1					
16	F4-04060004	油封 10.8×21×7	OIL SEAL 10.8x21x7	2					
17	F4-03000009	倒档齿轮垫圈	WASHER , REVERSE GEAR	1					
18	F4-03040000	倒档齿轮组件	REVERSE GEAR ASSY	1					
19	GB/T276-6004C2	深沟球轴承6004C2	DEEP GROOVE BALL BEARING 6004C2	2					
20	F4-03050002	油封13×22×7	OIL SEAL 13x22x7	2					
21	JISB2401-P48	水下装置壳体盖O形圈	O-RING P48	1					
22	F4-03050001	水下装置壳体盖	GEAR CASE GLAND	1					
23	GB/T5783-M6x20	六角头螺栓M6x20	HEXAGON BOLT M6x20	2					
24	F4-03000003	不带档边筒形轴承	CYLINDRICAL BEARING	1					
25	F4-03000023	注油孔螺塞	PLUG, STRAIGHT SCREW	3					
26	F4-03000024	注油孔螺塞密封垫	GASKET, STRAIGHT SCREW PLUG	3					
27	F4-03000001	水下装置壳体	GEAR CASE	1					
28	GB/T896-6	开口挡圈6	CIRCLIP 6	1					
29	F4-03000007	主动齿轮	PINION	1					
30	F4-03000006	主动齿轮垫圈	WASHER , PINION	1					
31	F4-03000002	带档边筒形轴承	CYLINDRICAL BEARING	1					
32	F4-03000008	变档柱塞	PLUGER , SHIFT	1					
33	F4-03010000	正档齿轮组件	FORWARD GEAR ASSY	1					
34	F4-03030002	离合器块	CLUTCH	1					
35	F4-03030003	离合器块压簧	SPRING , CLUTCH	1					
36	F4-03030001	螺旋桨轴	SHAFT , PROPELLER	1					
37	F4-03000004L	驱动轴（长轴）	SHAFT , DRIVE (L)	1					L
	F4-03000004S	驱动轴（短轴）	SHAFT , DRIVE (S)						S
38	F4-03000016	叶轮定位销	PIN	2					
39	F4-03000005	轴用钢丝挡圈	CLIP	1					
40	GB/T5782-M6x170	六角头长螺栓M6x170	HEXAGON BOLT M6x170	2					L
	GB/T5783-M6x40	六角螺栓M6x40	HEXAGON BOLT M6x40						S
41	GB/T879.4-1.5x20	弹性圆柱销 φ1.5×20	PIN, SPRING φ1.5×20	1					
42	F4-03050000	水下装置壳体盖组件	GLAND ASSY, GEAR CASE	1					
43	F4-03000028	O形圈挡板	PLATE, O-RING	1					
44	GB/T818-M5x6	十字槽盘头螺钉 M5x6	PAN HEAD SCREW M5x6	2					

零部件名称:	水下装置壳体 & 驱动系统
PARTS NAME:	LOWER CASING & DRIVE




SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	GB/T91-2.5x30	开口销 ϕ2.5×30	COTTER PIN ϕ2.5×30	1					
2	F4-03080000	螺母组件	NUT ASSY	1					
3	F4-03000026	不锈钢垫片	WASHER, PROPELLER	1					
4	F4-03070000	螺旋桨组件	PROPELLER ASSY	1					
5	F4-03000025	不锈钢垫块	SPACER, PROPELLER	1					
6	F4-03000022	阳极	ANODE, GEAR CASE ASSY	1					
7	GB/T861.1-6	内齿锁紧垫圈6	WASHER, INTERNAL TOOCH 6	1					
8	GB/T97.1-6	平垫圈6	PLAIN WASHER 6	1					
9	GB/T5783-M6x14	六角头螺栓 M6x14	HEXAGON BOLT M6x14	1					
10	F4-00000001	空心定位销	HOLLOW PIN	2					
11	F4-02040001L	进水管（长轴）	WATER TUBE ASSY (L)	1					L
	F4-02040001S	进水管（短轴）	WATER TUBE ASSY (S)						S
12	F4-02040002	工形橡胶圈	I -SHAPED RUBBER BLOCK	1					
13	F4-03100000L	水下装置壳体总成（长轴）	GEAR CASE ASSY (L)	1					L
	F4-03100000S	水下装置壳体总成（短轴）	GEAR CASE ASSY (S)						S

零部件名称:	点火系统
PARTS NAME:	IGNITOR ASSY



SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-04000026	六角螺母 M10x1.25	HEXAGON NUT M10x1.25	1					
2	F4-04000021	飞轮垫圈	WASHER, FLYWHEEL	1					
3	F4-04000020	起动轴套	PULLEY, STANTER	2					
4	F4-04100000	飞轮组件	FLYWHEEL ASSY	1					
5	GB/T5783-M6x25	六角头螺栓M6x25	HEXAGON BOLT M6x25	2					
6	F4-04000038	点火线圈组件	IGNITION COIL ASSY	1					
7	GB/T5783-M6x12	六角头螺栓M6x12	HEXAGON BOLT M6x12	1					
8	GB/T97.1-6	平垫圈6	PLAIN WASHER 6	3					
9	F4-04000019	半圆键	WOODRUFF KEY, FLYWHEEL	1					


零部件名称:	气缸&曲轴箱1
PARTS NAME:	CYLINDER & CRANKCASE 1



零部件名称: 气缸&曲轴箱1


PARTS NAME: CYLINDER & CRANKCASE 1

SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-04010100	曲轴箱体组件	CRANK CASE	1					
2	F4-04010102	气嘴	PIPE, JOINT	2					
3	F4-04010004	曲轴油封A 25x40x5	OIL SEAL A 25x40x5	1					
4	GB/T276-6205C3	深沟球轴承6205C3	DEEP GROOVE BALL BEARING 6205C3	1					
5	F4-04000009	呼吸器密封垫	GASKET, BREATHER	1					
6	F4-04000010	呼吸器盖板	COVER, BREATHER	1					
7	GB/T5783-M6x14	六角螺栓 M6x14	BOLHEXAGON BOLT M6x14	3					
8	GB/T97.1-6	平垫圈 6	PLAIN WASHER 6	3					
9	GB/T818-M4x6	十字槽盘头螺钉 M4x6	PAN HEAD SCREW M4x6	1					
10	F4-04010003	呼吸器阀片	VALVE, BREATHER	1					
11	F4-04000003	空心定位销 ϕ10x8.4x14	HOLLOW PIN ϕ10x8.4x14	2					
12	F4-04050200	曲轴箱盖组件	COVER, CRANK CASE	1					
13	F4-04000002	曲轴箱体复合垫	GASKET, CRANK CASE	1					
14	F4-04000039	凸缘螺栓 M8x50	HEXAGON BOLT M8x50	7					
15	F2.6-04010001	曲轴油封20x30x7(B)	OIL SEAL 20x30x7 (B)	1					
16	F4-04060004	驱动轴上油封10.8x21x7	OIL SEAL 10.8x21x7	2					
17	GB/T345.2-32.5x1.8	滤杯密封圈 32.5x1.8	O-RING 32.5x1.8	1					
18	F4-04060001	油封壳体	SHELL, OIL SEAL	1					
19	F4-04060000	油封壳体组件	SHELL ASSY, OIL SEAL	1					
20	GB/T97.1-8	平垫圈 8	PLAIN WASHER 8	8					
21	GB/T5783-M8x20	六角头螺栓 M8x20	HEXAGON BOLT M8x20	1					
22	F4-04000006	放油螺栓密封垫	GASKET, OIL DRAIN BOLT	1					
23	F4-04050100	甩油轮组件	OIL SPLASH GEAR ASSY	1					
24	GB/T5783-M6x12	六角头螺栓 M6x12	HEXAGON BOLT M6x12	1					
25	JASO F404-35-022	O型圈 22.4x3.5	O-RING 22.4x3.5	1					
26	F4-04000007	带尺机油盖	PLUG WITH DIPSTICK	1					
27	F4-04000001	放油螺栓	OIL DRAIN BOLT	1					
28	F2.6-04010103	出水嘴	WATER PIPE , OUT	1					
29	F4-04000036	带尺机油盖组件	PLUG WITH DIPSTICK ASSY	1					




SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-04020010	活塞环组件	PISTON RING ASSY	1					
2	F4-04020006	活塞销卡簧	CIRCLIP,PISTON PIN	2					
3	F4-04020005	活塞销	PIN ,PISTON	1					
4	F4-04020001	活塞	PISTON	1					
5	F4-04020100	连杆组件	CONNECTING ROD ASSY	1					
6	F4-04030000	曲轴组件	CRANKSHAFT ASSY	1					
7	F4-04000004	箱盖减磨片	THRUST WASHER,CRANK CASE	1					
8	F4-04020200	活塞组件	PISTON ASSY	1					

零部件名称:	凸轮轴&阀门
PARTS NAME:	CAMSHAFT & VALVE




SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-04040000	凸轮减压组件	CAMSHAFT ASSY	1					
2	166F-000001	气门挺柱	LIFTER, VALVE STEM	2					
3	F4-04000015	气门推杆	PUSH ROD, VALVE STEM	2					
4	F4-04080009	导向板	PLATE, PUSH ROD	1					
5	166F-010008	摇臂螺杆	SCREW BOLT, ROCKER ARM	2					
6	166F-010009	气门摇臂	ROCKER ARM, VALVE	2					
7	166F-010010	摇臂球座	PIVOT, ROCKER ARM	2					
8	166F-010011	锁紧螺母M6x0.75	HEXAGON KNUT M6×0.75	2					
9	F4-04080005A	进气门	DOOR, INTAKE	1					
10	F4-04080006A	排气门	DOOR, EXHAUST	1					
11	F4-04080007	气门弹簧垫圈	WASHER, VALVE SPRING	2					
12	166F-010003	气门油封	OIL SEAT, VALVE STEM	2					
13	F4-04080008	气门弹簧	SPRING, VALVE STEM	2					
14	F8-05030006	气门弹簧座圈	RETAINER, VALVE SPRING	2					
15	F8-05030007	气门锁夹	CLAMP, VALVE	2					

零部件名称:	气缸 & 曲轴箱 2
PARTS NAME:	CYLINDER & CRANKCASE 2



SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	GB/T5783-M6x16	六角头螺栓M6×16	HEXAGON BOLT M6×16	4					
2	F4-04000018	缸头罩	COVER, CYLINDER HEAD	1					
3	F4-04000017	缸头罩密封垫	GASKET , CYLINDER COVER	1					
4	F4-04080100	气缸头组件	CYLINDER HEAD ASSY	1					
5	F4-04000003	空心定位销	HOLLOW PIN	2					
6	F4-04000014	缸头复合垫	GASKET, CYLINDER HEAD	1					
7	GB/T5782-M6x45	六角螺栓M6×45	HEXAGON BOLT M6x45	1					
8	BPR7HS	火花塞	SPARK PLUG	1					
9	F4-04000034	气缸头螺栓B	BOLT "B", CYLINDER HEAD	3					
10	F4-04000033	气缸头螺栓A	BOLT "A", CYLINDER HEAD	1					
11	GB/T5783-M8x14	六角螺栓 M8x14	HEXAGON BOLT M8x14	1					
12	F4-04000006	放油螺栓密封垫	GASKET, OIL DRAIN BOLT	1					
13	T15-04000010	节温器	THERMOSTAT	1					
14	GB/T97.1-6	平垫圈6	PLAIN WASHER 6	8					
15	GB/T5783-M6x20	六角头螺栓M6×20	HEXAGON BOLT M6×20	3					
16	F4-04000012	回水管	WATER PIPE, RETURN	1					
17	F4-04010102	水咀	PIPE, JOINT	1					
18	F4-04070101	节温器盖	COVER , THERMOSTAT	1					
19	F4-04070100	节温器盖水咀组件	THERMOSTAT COVER ASSY	1					
20	F4-04000011	节温器盖密封垫	GASKET, THERMOSTAT COVER	1					
21	F4-04070003	节温器盖阳极	ANODE, THERMOSTAT COVER	1					
22	GB/T818-M5x25	十字槽盘头螺钉M5×25	PAN HEAD SCREW M5×25	1					



1
2
3
4
31
32
33
34
5
6
7
8
9
10
11
14
15
16
19
17
18
12
13
20
21
22
25
26
23
24
27
28
29
30

零部件名称: 燃油系统


PARTS NAME: FUEL

SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	GB/T823-M4x25	十字槽小盘头螺钉M4×25	PAN HEAD SCREW M4×25	4					
2	F4-04090003	燃油泵盖	COVER, FUEL PUMP	1					
3	F4-04090004	上隔膜	TOP DIAPHRAGM, FUEL PUMP	1					
4	F4-04090100A	燃油泵壳	FUEL PUMP SHELL	1					
5	F4-04090100	隔膜组件	DIAPHRAGM ASSY	1					
6	GB/T309-3x12	滚针φ3×12	ROLLER NEEDLE φ3×12	1					
7	F4-04090008	隔膜弹簧	SPRING, DIAPHRAGM	1					
8	F4-04090001	燃油泵座	SEAT, FUEL PUMP	1					
9	F4-04090007	柱塞弹簧	SPRING, PLUNGER	1					
10	F4-04090006	柱塞	PLUNGER	1					
11	GB/T6170-M4	螺母M4	NUT M4	4					
12	F4-04090000	燃油泵组件	FUEL PUMP ASSY	1					
13	F4-04090009	燃油泵座O形圈	O-RING	1					
14	F4-04000031-2	尼龙管夹（B）	CLIP, NYLON "B"	1					
15	F4-04000028	燃油管E	FUEL PIPE "E"	1					φ10×φ5×260
16	F4-04000030	油管夹簧B	SPRING, FUEL PIPE "B"	9					
17	GB/T93-6	弹簧垫圈6	WASHER, SPRING 6	2					
18	GB/T97.1-6	平垫圈6	PLAIN WASHER 6	2					
19	GB/T5783-M6x30	六角头螺栓M6x30	HEXAGON BOLT M6x30	2					
20	F4-05000008	燃油管D	FUEL PIPE "D"	1					φ10×φ5×60
21	F4-05000300	燃油过滤器组件	FUEL FILTER ASSY	1					
22	F4-05000007	燃油管C	FUEL PIPE "C"	2					
23	F15-05000011	三通	THREE THROUGH	1					
24	F4-05000200	燃油管接头组件	FUEL LINE CONNECTOR ASSY(ENGINE MALE)	1					
25	F4-05000006	燃油管B	FUEL PIPE "B"	1					
26	F4-05000100	油开关	FUEL COCK	1					
27	F4-05000010	油管夹簧A	CLIP A, FUEL PIPE	1					
28	F4-05000005	燃油管A	FUEL PIPE "A"	1					
29	F4-05000101	油开关旋钮	ROTARY KNOB, FUEL COCK	1					
30	GB/T818-M4x12	十字槽盘头螺钉 M4×12	PAN HEAD SCREW M4×12	1					
31	F4-04090001A	瓣膜B	VALVE "B"	1					
32	F4-04090002A	瓣膜A	VALVE "A"	1					
33	F4-04090003A	隔膜限位块	LIMITING BLOCK, SEPTUM	1					
34	GB/T819.2-M3x5	十字槽盘头螺钉 M3x5	PAN HEAD SCREW M3x5	2					


零部件名称:	进气系统
PARTS NAME:	INTAKE



SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	GB/T5782-M6x90	六角头螺栓 M6x90	HEXAGON BOLT M6x90	2					
2	GB/T97.1-6	平垫圈6	PLAIN WASHER 6	4					
3	F4-04110000	进气消音器组件	INTAKE SILENCER ASSY	1					
4	JASO F404-24-031	O形密封圈 24-031	O-RING 24-031	1					
5	F4-04000024	化油器密封垫	GASKET, CARBURETOR	2					
6	F4-04000025	化油器垫块	CUSHION BLOCK, CARBURETOR	1					
7	F4-04110003	消音器堵塞	JAM, INTAKE SILENCER ASSY	2					
8	F4-04000035	回气管	PIPE , RETURN AIR	1					
9	F4-04000031-1	尼龙管夹 (A)	CLAMP "A", NYLON	1					
10	F4-05000400	阻风门拉柄组件	CHOKE HANDLE ASSY	1					
11	F4-04000022	进气歧管密封垫	GASKET, INTAKE MANIFOLD	1					
12	F4-04000023	进气歧管	INTAKE MANIFOLD	1					
13	GB/T5783-M6x25	六角头螺栓 M6x25	HEXAGON BOLT M6x25	2					
14	F4-04140000	化油器	CARBURETOR	1					
15	F4-04000042	回气管 B	PIPE "B", RETURN AIR	1					ϕ2×ϕ7×85



SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-04120001	油箱	BUILT-IN FUEL TANK	1					
2	F4-04120100	油箱盖组件	FUEL TANK CAP ASSY	1					
3	F4-04120004	油箱口减震圈	BUSHING, FUEL TANK	1					
4	GB/T5783-M6x25	六角头螺栓 M6x25	HEXAGON BOLT M6x25	1					
5	F4-04120002	油箱减震器	DAMPER, FUEL TANK	3					
6	F4-04120003	减震器衬管	BUSHING, DAMPER	3					
7	F4-04000030	油管夹簧B	CLIP "B", FUEL PIPE	1					
8	F4-04120005	油箱滤油芯	FILTER, FUEL TANK	1					
9	GB/T97.1-6	平垫圈6	PLAIN WASHER 6	1					



1
23
19
17
22
16
2
24
25
21
3
6
20
19
4
5
15
18
26
14
13
7
8
8
9
9
12
11
10

零部件名称: 起动器组件


PARTS NAME: STARTER

SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-04130000	起动器组件	STARTER ASSY	1					
2	F4-04130001	起动器外壳	CASE, STARTER ASSY	1					
3	F4-04130018	起动减震块	RUBBER DAMPER, STARTER ASSY	1					
4	F4-04130101	起动手柄	HANDLE, STARTER	1					
5	F4-04130102	起动手柄盖	HANDLE COVER, STARTER	1					
6	F4-04130013	起动绳导管	MEATUS, START ROPE	1					
7	F4-04130011	锦纶编织线φ4.5x1.80m	STARTER ROPE	1					
8	F4-04130004	卡瓣弹簧	SPRING, DRIVE PAWL	2					
9	F4-04130003	卡瓣	PAWL, DRIVE	2					
10	F4-04130008	起动压板螺钉	SCREW, STARTER CLAMP PLATE	1					
11	F4-04130006	起动压板	STARTER CLAMP PLATE	1					
12	F4-04130007	起动压板夹簧	SPRING, STARTER CLAMP PLATE	1					
13	F4-04130019	起动轮	SHEAVE, STARTER	1					
14	F4-04130005	涡形弹簧	VOLUTE SPRING	1					
15	F4-04130014	起动轮减磨片	WASHER, STARTER SHEAVE	1					
16	F4-04130010	制动器扭簧	TWIST SPRING, DETENT	1					
17	F4-04130009	制动器	DETENT	1					
18	F4-08000013	标贴13	STICKER 13	1					
19	GB/T97.1-6	平垫圈6	PLAIN WASHER 6	3					
20	GB/T5783-M6x35	六角头螺栓 M6x35	HEXAGON BOLT M6x35	2					
21	F4-08000009	标贴9	STICKER 9	1					
22	F4-08000016	标贴16	STICKER 16	1					
23	GB/T5783-M6x20	六角头螺栓 M6x20	HEXAGON BOLT M6x20	1					
24	F4-04000005	钢索固定架	FIXED PLATE, DETENT TIGHTWIRE	1					
25	F4-02000013	制动器钢索组件	TIGHTWIRE ASSY, DETENT	1					
26	F4-04130100	起动手柄组件	STARTER HADLE ASSY	1					


零部件名称:	底罩
PARTS NAME:	BOTTOM COWLING




SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-05000001-A	底罩	BOTTOM COWLING	1					
2	GB/T818-M6x14	十字槽盘头螺钉 M6x14	PAN HEAD SCREW M6x14	2					
3	GB/T97.1-6	平垫圈6	PLAIN WASHER 6	12					
4	GB/T889.1-M5	非金属嵌件六角锁紧螺母M5	NUT,LOCKING M5	2					
5	F4-05000016-A	手把	CARRYING HANDLE	1					
6	GB/T5783-M6x25	六角头螺栓 M6x25	HEXAGON BOLT M6x25	1					
7	F4-05000020	顶罩锁紧钩座组件	SEAT ASSY,LOCKING HOOK	2					
8	GB/T97.1-5	平垫圈 5	PLAIN WASHER 5	4					
9	GB/T818-M5x16	十字槽盘头螺钉M5x16	PAN HEAD SCREW M5x16	2					
10	F4-05000023	顶罩锁紧钩	LOCKING HOOK	2					
11	GB/T6170-M6	六角螺母 M6	HEXAGON NUT M6	1					
12	GB/T818-M6x12	十字槽盘头螺钉M6x12	PAN HEAD SCREW M6x12	2					
13	GB/T5783-M6x14	六角头螺栓M6x14	HEXAGON BOLT M6x14	7					
14	F4-05000013-2	橡胶闷盖B	COVER,RUBBER	1					



SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-06000000-A	顶罩组件	TOP COWLING ASSY	1					
2	F4-08000001	标贴1	STICKER 1	1					
3	F4-08000003	标贴3	STICKER 3	1					F4
	F4-08000005	标贴5	STICKER 5	1					F5
4	F4-08000004	标贴4	STICKER 4	1					F4
	F4-08000006	标贴6	STICKER 6	1					F5
5	F4-08000019	标贴19	STICKER 19	1					
6	F4-08000002	标贴2	STICKER 2	1					
7	F4-06000002-A	密封橡胶条	RUBBER SEAL, TOP COWLING	1					
8	GB/T845-ST5.5x19	十字槽盘头自攻螺钉ST5.5x19	PAN HEAD SCREW ST5.5x19	4					
9	F4-06000004	橡胶垫片	RUBBER GASKET	4					
10	F4-06000003-A	顶罩消音盖	COVER, TOP COWING MUFFLING	1					
11	F4-06000001-A	顶罩	TOP COWLING	1					



SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F15-09000000	油管总成	FUEL LINE ASSY	1					
2	F8-10000000	油箱组件 (12L)	PORTABLE FUEL TANK ASSY (12L)	1					
3	F15-10010000	油箱盖组件	CAP ASSY, FUEL TANK	1					
4	GB/T818-M5x16	十字槽盘头螺钉M5×16	PAN HEAD SCREW M5x16	4					
5	GB/T97.1-5	平垫圈5	PLAIN WASHER 5	4					
6	F15-10020000	油量计总成	OLEOMETER ASSY	1					
7	F15-10000003	衬垫	GASKET, OLEOMETER ASSY	1					
8	F15-10000002	油箱滤网	STRAINER, FUEL TANK	1					
9	F8-10000001	油箱本体	FUEL TANK	1					(12L)
10	JASO F404-78-31	O形圈7.8x3.1	O-RING 7.8x3.1	2					
11	F15-09020000	燃油接头组件(出)	FUEL LINE CONNECTOR(ENGINE SIDE, FEMALE)	1					
12	F15-09000003	卡箍 B	CLAMP B	4					
13	F15-09000001	油管A(ϕ10xϕ6ϕ2080)	FUEL LINE A(ϕ10xϕ6x2080)	1					
14	F15-09030000	手动油泵组件	PRIMER BULB ASSY	1					
15	F15-09000002	油管B(ϕ10xϕ6ϕ850)	FUEL LINE B(ϕ10xϕ6x850)	1					
16	F15-09010000	燃油接头组件(进)	FUEL LINE CONNECTOR(FUEL TANK SIDE, FEMALE)	1					



1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
3
21

零部件名称: 化油器总成

PARTS NAME: CARBURETOR ASSY


SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-04140000	化油器总成	CARBURETOR ASSY	1					
2	GB/T818-M4X10	十字槽盘头螺钉 M4x10	PAN HEAD SCREW M4x10	3					
3	GB/T94.1-4	弹性垫圈4	SPRING WASHER 4	5					
4	F4-04140002	面板	PLATE	1					
5	F4-04140003	衬垫	GASKET	1					
6	F4-04140004	油门调节螺钉	ADJUSTING SCREW, THROTTLE	1					
7	F4-04140005	调节弹簧	ADJUSTING SPRING, THROTTLE	1					
8	F4-04140008	空气调节螺钉O型圈	O-RING, AIR	1					
9	F4-04140009	空气调节螺钉	ADJUSTING SCREW, AIR	1					
10	F4-04140010	空气减速量孔	JET, AIR SLOW	1					
11	F4-04140011	主量孔	MAIN JET	1					
12	F4-04140012	针阀	NEEDLE VALVE	1					
13	F4-04140013	主喷嘴	MAIN NOZZLE	1					
14	F4-04140014	胶帽	RUBBER CAP	1					
15	F4-04140200	浮子	FLOAT	1					
16	F4-04140018	浮子销	PIN, FLOAT	1					
17	F4-04140019	油杯O型圈	O-RING, FLOAT CHAMBER	1					
18	F4-04140301	放油螺塞	FUEL DRAIN BOLT	1					
19	F4-04140302	放油螺塞垫片	GASKET, FUEL DRAIN BOLT	1					
20	F4-04140300	浮子本体组件	BODY, FLOAT CHAMBER	1					
21	GB/T818-M4x12	十字槽盘头螺钉 M4x12	PAN HEAD SCREW M4x12	2					

零部件名称:	气缸头总成（修理件）
PARTS NAME:	CYLINDER HEAD ASSY (REPARE KIT)



SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-04080000	气缸头总成	CYLINDER HEAD ASSY	1					
2	F4-04080101	气缸头	CYLINDER HEAD	1					
3	F4-04080009	导向板	PLATE, PUSH ROD	1					
4	166F-010008	摇臂螺杆	SCREW BOLT, ROCKER ARM	2					
5	166F-010009	气门摇臂	ROCKER ARM, VALVE	2					
6	166F-010010	摇臂球座	PIVOT, ROCKER ARM	2					
7	166F-010011	锁紧螺母M6x0.75	HEXAGON NUT M6x0.75	2					
8	F4-04080005A	进气门	DOOR, INTAKE	1					
9	F4-04080006A	排气门	DOOR, EXHAUST	1					
10	F4-04080007	气门弹簧垫圈	WASHER, VALVE SPRING	2					
11	166F-010003	气门油封	OIL SEAT, VALVE STEM	2					
12	F4-04080008	气门弹簧	SPRING, VALVE STEM	2					
13	F4-05030006	气门弹簧座	RETAINER, VALVE SPRING	2					
14	F4-05030007	气门锁片	CLAMP, VALVE	2					
15	GB/T5783-M8x14	六角螺栓 M8x14	HEXAGON BOLT M8x14	1					
16	F4-04000006	放油螺栓密封垫	GASKET, OIL DRAIN BOLT	1					

零部件名称:	发动机头组件（修理件）
PARTS NAME:	ENGINE ASSY (REPARE KIT)



零部件名称: 发动机头组件（修理件）


PARTS NAME: ENGINE ASSY（REPARE KIT）

SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-04150000	发动机头组件	ENGINE BLOCK ASSY	1					
2	F4-04010100	曲轴箱体组件	CRANK CASE	1					
3	F4-04010102	气嘴	PIPE, JOINT	2					
4	F4-04010004	曲轴油封 A 25x40x5	OIL SEAL A 25x40x5	1					
5	GB/T276-6205C3	深沟球轴承6205C3	DEEP GROOVE BALL BEARING 6205C3	1					
6	F4-04000009	呼吸器密封垫	GASKET, BREATHER	1					
7	F4-04000010	呼吸器盖板	COVER, BREATHER	1					
8	GB/T5783-M6x14	六角头螺栓M6x14	HEXAGON BOLT M6x14	3					
9	GB/T97.1-6	平垫圈6	PLAIN WASHER 6	3					
10	GB/T818-M4x6	十字槽盘头螺钉M4x6	PAN HEAD SCREW M4x6	1					
11	F4-04010003	呼吸器阀片	VALVE, BREATHER	1					
12	F4-04000003	空心定位销 ϕ10x8.4x14	HOLLOW PIN ϕ10x8.4x14	2					
13	F4-04050200	曲轴箱盖组件	COVER, CRANK CASE	1					
14	F4-04000002	曲轴箱体复合垫	CRANK CASE COMPLEX GASKET	1					
15	F4-04000039	凸缘螺栓M8x50	FLANGE BOLT M8x50	7					
16	F2.6-04010001	曲轴油封20x30x7(B)	OIL SEAL 20x30x7(B)	1					
17	F4-04060004	驱动轴上油封10.8x21x7	OIL SEAL 10.8x21x7	2					
18	GB/T345.2-32.5x1.8	滤杯密封圈 32.5x1.8	O-RING 32.5x1.8	1					
19	F4-04060001	油封壳体	SHELL, OIL SEAL	1					
20	F4-04060000	油封壳体组件	OIL SEAL SHELL ASSY	1					
21	GB/T97.1-8	平垫圈8	PLAIN WASHER 8	8					
22	GB/T5783-M8x20	六角头螺栓M8x20	HEXAGON BOLT M8x20	1					
23	F4-04000006	放油螺栓密封垫	GASKET, OIL DRAIN BOLT	1					
24	F4-04050100	甩油轮组件	OIL SPLASH GEAR ASSY	1					
25	GB/T5783-M6x12	六角头螺栓M6x12	HEXAGON BOLT M6x12	1					
26	JASO F404-35-022	O型圈 22.4x3.5	O-RING 22.4x3.5	1					
27	F4-04000007	带尺机油盖	PLUG WITH DIPSTICK	1					
28	F4-04000001	放油螺栓	OIL DRAIN BOLT	1					
29	F2.6-04010103	出水嘴	WATER PIPE, OUT	1					
30	F4-04000036	带尺机油盖组件	PLUG WITH DIPSTICK ASSY	1					
31	T15-04000010	节温器	THERMOSTAT	1					
32	GB/T97.1-6	平垫圈6	PLAIN WASHER 6	8					
33	GB/T5783-M6x20	六角头螺栓 M6x20	HEXAGON BOLT M6x20	3					
34	F4-04040000	凸轮减压组件	CAMSHAFT ASSY	1					
35	F4-04010102	水咀	PIPE, JOINT	1					
36	F4-04070101	节温器盖	COVER , THERMOSTAT	1					
37	F4-04070100	节温器盖水咀组件	THERMOSTAT COVER ASSY	1					
38	F4-04000011	节温器盖密封垫	GASKET, THERMOSTAT COVER	1					
39	F4-04070003	节温器盖阳极	ANODE, THERMOSTAT COVER	1					
40	GB/T818-M5x25	十字槽盘头螺钉 M5x25	PAN HEAD SCREW M5x25	1					
41	F4-04030000	曲轴组件	CRANKSHAFT ASSY	1					
42	F4-04000004	箱盖减磨片	THRUST WASHER, CRANK CASE	1					
43	F4-04020100	连杆组件	CONNECTING ROD ASSY	1					

零部件名称: 发动机头组件（修理件）

PARTS NAME: ENGINE ASSY（REPARE KIT）

SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
44	F4-04020200	活塞组件	PISTON ASSY	1					
45	F4-04020010	活塞环组件	PISTON RING ASSY	1					
46	F4-04020006	活塞销卡簧	CIRCLIP,PISTON PIN	2					
47	F4-04020005	活塞销	PISTON PIN	1					
48	F4-04020001	活塞	PISTON	1					


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
22
23
24

零部件名称: 附录(修理件)

PARTS NAME: APPENDIX (REPARE KIT)

SN. 参照号码	PART NO. 零件编号	DESCRIPTION 零件名称(中文)	DESCRIPTION 零件名称(英文)	QTY 数量					REMARKS 备注
1	F4-04000017	缸头罩密封垫	GASKET, CYLINDER COVER	1					
2	F4-04000014	缸头复合垫	GASKET, CYLINDER HEAD	1					
3	F4-04000009	呼吸器密封垫	GASKET, BREATHER	1					
4	F4-04010004	曲轴油封A 25×40×5	OIL SEAL A 25x40x5	1					
5	F4-04090009	燃油泵座O形圈	O-RING	1					
6	F4-04000002	曲轴箱体复合垫	CRANA CASE COMPLEX GASKET	1					
7	F2.6-04010001	曲轴油封B 20×30×7	OIL SEAL B 20x30x7	1					
8	F4-04060004	驱动轴上油封 10.8×21×7	OIL SEAL 10.8x21x7	2					
9	F4-04060002	油封壳体O形圈	O-RING	1					
10	F4-00000006	发动机密封垫	GASKET, ENGINE	1					
11	JISB2401-P48	水下装置壳体盖O形圈 P48	O-RING P48	1					
12	F4-03050002	油封 13x22x7	OIL SEAL 13x22x7	2					
13	F4-03000024	注油孔螺塞垫圈	GASKET, STRAIGHT SCREW PLUG	3					
14	F4-03000027	油封 10.8×21×7	OIL SEAL 10.8x21x7	2					
15	F4-03000011	水泵座密封垫	GASKET, WATER PUMP BASE	1					
16	F2.6-03000009	O形密封圈	O-RING	1					
17	F4-03060000	水泵叶轮	IMPELLER, WATER PUMP	1					
18	F4-03000018	泵壳密封垫	GASKET, WATER PUMP COVER	1					
19	F4-03000021	泵壳橡胶管	RUBBER TUBE, WATER PUMP	1					
20	JASO F404-35-022	O型圈 22.4x3.5	O-RING 22.4-3.5	1					
21	F4-04000022	进气弯管密封垫	GASKET, INTAKE MANIFOLD	1					
22	F4-04000024	化油器密封垫	GASKET, CARBURETOR	2					
23	JASO F404-24-031	O形密封圈 24-031	O-RING 24-031	1					
24	F4-04000011	节温器盖密封垫	GASKET, THERMOSTAT COVER	1					

零部件名称: 零件目录检索表

PARTS NAME: PARTS CATALOGUE INDEX

零件代号 PART NO.	页码/序号 PAGE/NO.	零件代号 PART NO.	页码/序号 PAGE/NO.	零件代号 PART NO.	页码/序号 PAGE/NO.
BPR7HS	15-8	F4-01030005	3-17	F4-03000012	8-14
JASO F404-24-031	18-4	F4-01030100	3-18	F4-03000013	8-4
JASO F404-31-008	24-10	F4-01030103	3-13	F4-03000015	8-9
JASO F404-35-022	12-25	F4-01050000	3-4	F4-03000016	8-38
JB/T7940.1-M6	6-5	F4-01060000	3-38	F4-03000017	8-7
JISB2401-P48	8-21	F4-01060001	3-37	F4-03000018	8-6
JISB2401-P9	1-3	F4-01060002	3-35	F4-03000019	8-5
		F4-01070000	3-23	F4-03000020	7-2
		F4-01090001	5-1	F4-03000021	7-3
T15-04000010	15-13	F4-01090002	5-22	F4-03000022	9-6
166F-000001	14-2	F4-01090003	5-19	F4-03000023	8-25
166F-010003	14-12	F4-01090004	5-27	F4-03000024	8-26
166F-010008	14-5	F4-01090006	5-14	F4-03000025	9-5
166F-010009	14-6	F4-01090007	5-15	F4-03000026	9-3
166F-010010	14-7	F4-01090008	5-24	F4-03000028	8-43
166F-010011	14-8	F4-01090100	5-20	F4-03010000	8-33
F2.6-03000009	8-10	F4-01090200	5-12	F4-03020000L	8-11
F2.6-04010001	12-15	F4-01090300	5-18	F4-03020000S	
F2.6-04010103	12-28	F4-01090400	5-26	F4-03030001	8-36
		F4-01090401	5-25	F4-03030002	8-34
		F4-02000002	6-13	F4-03030003	8-35
F4-00000001	6-2	F4-02000003	1-5	F4-03040000	8-18
F4-00000001	9-10	F4-02000004	1-11	F4-03050000	8-42
F4-00000003	1-12	F4-02000006	1-10	F4-03050001	8-22
F4-00000004	1-13	F4-02000007	3-2	F4-03050002	8-20
F4-00000005	1-14	F4-02000008	3-1	F4-03060000	8-8
F4-00000006	6-1	F4-02000009	3-24	F4-03070000	9-4
F4-00000007	1-1	F4-02000011	6-7	F4-03080000	9-2
F4-01000002	3-6	F4-02000012	6-8	F4-03100000L	9-13
F4-01000003	3-12	F4-02000013	21-25	F4-03100000S	
F4-01000004	3-25	F4-02000100	6-6	F4-04000001	12-27
F4-01000005	3-33	F4-02010000-A	1-2	F4-04000002	12-13
F4-01000006	3-20	F4-02020000	3-3	F4-04000003	12-11
F4-01000007	3-21	F4-02030001	6-12		15-5
F4-01000008	5-7	F4-02030002	6-11	F4-04000004	13-7
F4-01000009	5-2	F4-02030003	6-10	F4-04000005	21-24
F4-01000010	5-4	F4-02040001L	9-11	F4-04000006	12-22
F4-01000011	5-6	F4-02040001S		F4-04000006	15-12
F4-01000012	5-3	F4-02040002	9-12	F4-04000007	12-26
F4-01000014	5-8	F4-03000001	8-27	F4-04000009	12-5
F4-01010000	3-32	F4-03000002	8-31	F4-04000010	12-6
F4-01010002	3-28	F4-03000003	8-24	F4-04000011	15-20
F4-01010003	3-29	F4-03000004L	8-37	F4-04000012	15-16
F4-01010004	3-27	F4-03000004S		F4-04000014	15-6
F4-01010005	3-26	F4-03000005	8-39	F4-04000015	14-3
F4-01020000	3-7	F4-03000006	8-30	F4-04000017	15-3
F4-01030001	3-9	F4-03000007	8-29	F4-04000018	15-2
F4-01030002	3-15	F4-03000008	8-32	F4-04000019	10-9
F4-01030003	3-14	F4-03000009	8-17	F4-04000020	10-3
F4-01030004	3-19	F4-03000011	8-15	F4-04000021	10-2

零部件名称: 零件目录检索表

PARTS NAME: PARTS CATALOGUE INDEX

零件代号 PART NO.	页码/序号 PAGE/NO.	零件代号 PART NO.	页码/序号 PAGE/NO.	零件代号 PART NO.	页码/序号 PAGE/NO.
F4-04000022	18-11	F4-04090003A	17-33	F4-04140200	26-15
F4-04000023	18-12	F4-04090004	17-3	F4-04140300	26-20
F4-04000024	18-5	F4-04090006	17-10	F4-04140301	26-18
F4-04000025	18-6	F4-04090007	17-9	F4-04140302	26-19
F4-04000026	10-1	F4-04090008	17-7	F4-05000001-A	22-1
F4-04000028	17-15	F4-04090009	17-13	F4-05000005	17-28
F4-04000030	17-16	F4-04090100	17-5	F4-05000006	17-25
	19-7	F4-04090100A	17-4	F4-05000007	17-22
F4-04000031-1	18-9	F4-04100000	10-4	F4-05000008	17-20
F4-04000031-2	17-14	F4-04110000	18-3	F4-05000010	17-27
F4-04000033	15-10	F4-04110003	18-7	F4-05000013-2	22-14
F4-04000034	15-9	F4-04120001	19-1	F4-05000014	5-5
F4-04000035	18-8	F4-04120002	19-5	F4-05000016-A	22-5
F4-04000036	12-29	F4-04120003	19-6	F4-05000020	22-7
F4-04000038	10-6	F4-04120004	19-3	F4-05000023	22-10
F4-04000039	12-14	F4-04120005	19-8	F4-05000100	17-26
F4-04000042	18-15	F4-04120100	19-2	F4-05000101	17-29
F4-04010003	12-10	F4-04130000	21-1	F4-05000200	17-24
F4-04010004	12-3	F4-04130001	21-2	F4-05000300	17-21
F4-04010100	12-1	F4-04130003	21-9	F4-05000400	18-10
F4-04010102	12-2	F4-04130004	21-8	F4-06000000-A	23-1
	15-17	F4-04130005	21-14	F4-06000001-A	23-11
F4-04020001	13-4	F4-04130006	21-11	F4-06000002-A	23-7
F4-04020005	13-3	F4-04130007	21-12	F4-06000003-A	23-10
F4-04020006	13-2	F4-04130008	21-10	F4-06000004	23-9
F4-04020010	13-1	F4-04130009	21-17	F4-08000001	23-2
F4-04020100	13-5	F4-04130010	21-16	F4-08000002	23-6
F4-04020200	13-8	F4-04130011	21-7	F4-08000003	23-3
F4-04030000	13-6	F4-04130013	21-6	F4-08000004	23-4
F4-04040000	14-1	F4-04130014	21-15	F4-08000005	23-3
F4-04050100	12-23	F4-04130018	21-3	F4-08000006	23-4
F4-04050200	12-12	F4-04130019	21-13	F4-08000009	21-21
F4-04060000	12-19	F4-04130100	21-26	F4-08000012	5-13
F4-04060001	12-18	F4-04130101	21-4	F4-08000013	21-18
F4-04060004	8-16	F4-04130102	21-5	F4-08000014	5-10
F4-04060004	12-16	F4-04140000	18-14	F4-08000015	5-23
F4-04070003	15-21	F4-04140000	26-1	F4-08000016	21-22
F4-04070100	15-19	F4-04140002	26-4	F4-08000018	3-8
F4-04070101	15-18	F4-04140003	26-5	F4-08000019	23-5
F4-04080005A	14-9	F4-04140004	26-6		
F4-04080006A	14-10	F4-04140005	26-7		
F4-04080007	14-11	F4-04140008	26-8		
F4-04080008	14-13	F4-04140009	26-9	F8-05030006	14-14
F4-04080009	14-4	F4-04140010	26-10	F8-05030007	14-15
F4-04080100	15-4	F4-04140011	26-11	F8-10000000	24-2
F4-04090000	17-12	F4-04140012	26-12	F8-10000001	24-9
F4-04090001	17-8	F4-04140013	26-13		
F4-04090001A	17-31	F4-04140014	26-14		
F4-04090002A	17-32	F4-04140018	26-16		
F4-04090003	17-2	F4-04140019	26-17	F15-05000011	17-23

零部件名称:	零件目录检索表
PARTS NAME:	PARTS CATALOGUE INDEX

零件代号 PART NO.	页码/序号 PAGE/NO.	零件代号 PART NO.	页码/序号 PAGE/NO.	零件代号 PART NO.	页码/序号 PAGE/NO.
F15-09000000	24-1				
F15-09000001	24-13				
F15-09000002	24-15				
F15-09000003	24-12				
F15-09010000	24-16				
F15-09020000	24-11				
F15-09030000	24-14				
F15-10000002	24-8				
F15-10000003	24-7				
F15-10010000	24-3				
F15-10020000	24-6				