




HK PARTS LIST

HK-5,6HP


1 汽油机 1 GASOLINE ENGINE



1 汽油机
1ASOLINE ENGINE

序号 Ref No	图号 Part No	名称及规格 Description	数量 Q'ty	序号 Ref No	图号 Part No	名称及规格 Description	数量 Q'ty
1-1		起动机总成 STARTER ASSY	1	1-24		化油器垫片 CARBUFETOR GASKET	1
1-2	GB5781	螺栓 M6×25 BOLT M6×25	3	1-25	GB5781	螺栓 M6×52 BOLT M6×52	4
1-3	GB5781	螺栓 M6×12 BOLT M6×12	3	1-26	GB5781	螺栓 M6×35 BOLT M6×35	2
1-4		被动盘 DRIVING PLATE STARTER	1	1-27		曲轴箱盖 CRANKCASE	1
1-5	GB/T6170	螺母 M12×1.25 NUT M12×1.25	1	1-28		进气阀簧片 VALVE REED FOR ADMISSION	1
1-6	GB/T95	平垫圈 12 WASHER 12	1	1-29		进气阀压板 VALVE CLAMP FOR ADMISSION	1
1-7		飞轮总成 FIYWHEEL	1	1-30	GB/T9074.4	十字槽盘头螺丝组合 SCREW M5×10	5
1-8		油封挡环 38×50×1.6 SEAL OIL RING 38×50×1.6	2	1-31		触发器过线套 TRIGGER WIRE BOX	1
1-9		油封 20×47×8 SEAL OIL 20×47×8	2	1-32		触发器 TRIGGER	1
1-10		半圆键 4×16 WOODRUFF KEY 4×16	1	1-33		线卡 CLAMP	1
1-11		曲轴连杆总成 CRANKSHAFT ASSEMBLY	1	1-34		火花塞 SPARK PLUG	1
1-12		滚针轴承 K14×18×20 NEEDLE BEARING K14×18×20	1	1-35	GB5781	螺栓 M8×35 BOLT M8×35	5
1-13	HK5S.15-2	传动轴保护套密封垫 TRANSMISSION SHAFT PROTECTOR GASKET	1	1-36		缸头盖 CYLINDER HEAD	1
1-14	HK5S.15-6	传动轴保护套油封 10×25×7 SEAL OIL 10×25×7	2	1-37		气缸盖衬垫 CYLINDER HEAD GASKET	1
1-15	HK5S.15-3	油封间隔圈 19×24.8×1 SEAL OIL SPACER 19×24.8×1	1	1-38		曲轴箱体 BLOCK ASSY CYLINDER	1
1-16	HK5S.15-1	传动轴保护套 TRANSMISSION SHAFT PROTECTOR	1	1-39		高压包 UNIT IGNITER	1
1-17	GB5781	螺栓 M6×20 BOLT M6×20	4	1-40		锡钢片 TUTANIA PATCH	1
1-18	HK2.5S.12 -04	熄火开关螺母 SWITCH EMERGENCY NUT	1	1-41	GB/T9074.4	十字槽盘头螺丝组合 M5×20 SCREW M5×20	2
1-19	GB5781	螺栓 M6×90 BOLT M6×90	2	1-42	GB/T119.2	销子 6×10 PIN 6×10	2
1-20		空滤器盖 AIR FILTER COVER	1	1-43		活塞环 PISTON RING	2
1-21	HK2.5S.12 -04	熄火开关拉绳 PLATE LOCK	1	1-44		活塞 PISTON	1
1-22	HK2.5S.12 -04	熄火开关 SWITCH EMERGENCY	1	1-45		活塞销 PISTON PIN	1
1-23		化油器总成 CARBUFETOR	1	1-46		活塞销卡簧 CLIP PISTON PIN	2

2 舵杆部件 2 DRIVE SHAFT HOUSING




2 艏杆部件

2 DRIVE SHAFT HOUSING

序号 Ref No	图号 Part No	名称及规格 Description	数量 Q'ty	序号 Ref No	图号 Part No	名称及规格 Description	数量 Q'ty
2-1	HK5S.15-5	连接密封垫 GASKET UPPER CASING	1	2-15	GB/T818	十字槽螺钉 M5×10 SCREW M5×10	2
2-2	GB119	销子 6×10 PIN 6×10	2	2-16	GB/T9074.14	组合螺栓 M6×26 BOLT M6×26	6
2-3	HK5S.13-2	出水管密封块 GROMMET WATER TUBE UPPER	1	2-17	GB/T9074.14	组合螺栓 M6×16 BOLT M6×16	1
2-4	HK5S.13-1	水泵出水管 TUBE WATER	1	2-18	HK5S.11-8	调整上压块 CONNECTOR CLUTCH ROD 2	1
2-5	HK5S.15-01	艏杆 UPPER CASING	1	2-19	HK5S.11-1	摆架拉杆 CLUTCH ROD	1
2-6	HK5S.11-14	O 型圈 12.5×1.6 “O”RING 12.5×1.6	2	2-20	HK5S.11-9	调整下压块 CONNECTOR CLUTCH ROD 1	1
2-7	HK5S.11-7	变档密封套 SHIFT SEAL BOX	1	2-21	GB5781	六角螺栓 M8×10 BOLT M8×10	1
2-8	HK5S.11-3	变档弹簧 SPRING CLUTCH NOTCH	1	2-22	GB/T95	垫圈 8 WASHER 8	1
2-9		定位钢珠 S8 BALL HOLDER S8	1	2-23	GB/T95	垫圈 6 WASHER 6	1
2-10	HK5S.11-01	变档手柄总成 LEVER CLUTCH	1	2-24	GB873	扁平头铆钉 FLAT HEAD RIVET	1
2-11	HK5S.11-11	自锁抓拉杆 SELF LOCK DETENT ROD	1	2-25	HK5S.11-2	变档摆架 ARM CLUTCH ROD	1
2-12	HK5S.11-15	拉杆锁扣 ROD LATCH	1	2-26	GB/T9074.12	十字槽螺钉组合 M4×16 SCREW M4×16	1
2-13	HK2.5S.15-3	调节孔盖（154S 通用） COVER CLUTCH ADJUST HOLE	1	2-27	GB/T91	开口销 1×14 PIN COTTER 1×14	1
2-14	HK5S.15-4	传动轴保持架 DRIVE SHIFT SUPPORT	1				

3 托架部件 3 CLAMP BRACKET




3 托架部件
3CLAMP BRACKET

序号 Ref No	图号 Part No	名称及规格 Description	数量 Q'ty	序号 Ref No	图号 Part No	名称及规格 Description	数量 Q'ty
3-1	GB5781	螺栓 M8×125 BOLT M8×125	1	3-24	GB95	平垫 8 WASHER 8	1
3-2	HK5S.17-11	右夹紧托架 RIGHT BRACKET CLAMP	1	3-25	GB/9074.14	六角螺栓组合 M6×14 BOLT M6×14	2
3-3	GB/T5287	特大垫圈 8 BIG WASHER 8	2	3-26	GB96	大垫圈 6 BIG WASHER 6	3
3-4	HK2.02-5	夹紧螺栓 (1E42S 通用) BOLT TRANSOM CLAMP	2	3-27	HK5S.17-22	锁勾右扭簧 RIGHT LATCH TORSION SPRING	1
3-5	GB/T6172.2	锁紧螺母 NUT M4	2	3-28	HK5S.17-02	倾斜锁勾 TILT LATCH	1
3-6	HK2.02-5	夹紧手柄 (1E42S 通用) HANDLE TRANSOM CLAMP	2	3-29	HK5S.17-21	锁勾左扭簧 LEFT LATCH TORSION SPRING	1
3-7	GB/819.1	十字槽沉头螺钉 M4×16 SCREW M4×16	2	3-30	HK5S.17-6	转架上密封圈 ROTATION FRAME SEAL GASKET	1
3-8	HK5S.17-1	大转架 BIG BRACKET CLAMP	1	3-31	HK5S.17-4	转架大减磨圈 BIG ROTATION ANTI-FRICTION RING	1
3-9	HK5S.17-20	锁定臂轴瓦 LOCKING ARM BEARING BUSH	2	3-32	GB/T70.1	内六角圆柱头螺钉 M6×35 SCREW M6×35	1
3-10	HK5S.17-01	上倾锁定臂 UP-TILT LOCKING ARM	1	3-33	HK5S.17-3	夹紧箍 CLAMP RING	1
3-11	HK5S.17-18	锁定臂手把套 LOCKING ARM BEARING BUSH	1	3-34	HK5S.17-5	转架小减磨圈 SMALL ROTATION ANTI-FRICTION RING	1
3-12	HK5S.17-17	锁定臂弹簧 LOCKING ARM SPRING	1	3-35	HK5S.17-7	转架轴瓦 ROTATION FRAME BEARING BUSH	2
3-13	HK5S.17-19	锁定臂压板 LOCKING ARM PLATE	1	3-36	GB/T6172.2	六角薄螺母 M6 NUT M6	1
3-14	GB/9074.14	六角螺栓组合 M6×12 BOLT M6×12	2	3-37	HK5S.17-2	小转架 SMALL BRACKET SWIVEL	1
3-15	GB/T818	十字槽螺钉 M4×6 SCREW M4×6	1	3-38	HK2.02-11	黄油嘴 (1E42S 通用) NIPPLE GREASE	2
3-16	GB/T5287	特大垫圈 4 BIG WASHER 4	1	3-39	GB/T9074.14	六角螺栓组合 M6×40 BOLT M6×40	4
3-17	HK5S.17-13	导向扭簧 REFERENCE TORSION SPRING	1	3-40	HK5S.17-9	转架锁紧压簧 SPRING COMPRESSION	1
3-18	HK5S.17-10	左夹紧托架 LEFT BRACKET CLAMP	1	3-41	HK5S.17-8	转架锁紧螺母 NUT COMPRESSION	1
3-19	HK5S.17-12	托架夹连接片 BRACKETGULCKCONNECT PATCH	1	3-42	HK5S.17-14	倾斜销 TILT PIN	1
3-20	GB/819.2	十字槽沉头螺钉 M6×12 SCREW M6×12	2	3-43	HK5S.17-15	倾斜销弹簧 TILT PIN SPRING	1
3-21	GB/T6172.2	锁紧螺母 M5 NUT M5	2	3-44	HK5S.17-16	倾斜销锁片 TILT LOCK PATCH	1
3-22	HK2.02-7	压盘 (1E42S 通用) PAD TRASOM CLAMP	2	3-45	GB/T879.2	弹性圆柱销 2.5×6 SPRING PIN 2.5×6	1
3-23	GB/T889.1	六角锁紧螺母 M8 NUT M8	1				

4 操纵手柄部件

4 TILLER HANDLE




4 操纵手柄部件
4 TILLER HANDLE

序号 Ref No	图号 Part No	名称及规格 Description	数量 Q'ty	序号 Ref No	图号 Part No	名称及规格 Description	数量 Q'ty
4-1	HK5S.12-1	操纵手柄 HANDLE TILLER	1	4-10	HK5S.12-11	转杆压板 STOPPER THROTTLE CABLE PLATE	1
4-2	HK5S.12-7	转把减磨套 TILLER HANDLE ANTI-FRICTION BUSH	1	4-11	GB/T818	十字槽盘头螺钉 M6×12 SCREW M6×12	1
4-3	HK5S.12-22	转杆橡胶 TURN ROD RUBBER	1	4-12		油门拉线总成 CABLE THROTTLE	1
4-4	HK5S.12-6	转把 HANDLE TILLER GRIP	1	4-13	GB/T93	弹垫 6 SPRING WASHER 6	2
4-5	GB/T68	开槽沉头螺钉 M5×20 SCREW M5×20	1	4-14	HK5S.12-2	操纵手柄挡板 TILLER HANDLE SEAL RING	1
4-6	HK5S.12-03	转轴调节手柄 AXLE THROTTLE HANDLE	1	4-15	HK5S.12-3	操纵手柄密封圈 TILLER HANDLE SEAL RING	2
4-7	HK5S.12-10	转杆调节器 STOPPER THROTTLE CABLE	1	4-16	HK5S.12-5	减磨片 32×45×1 ANTI-FRICTION PATCH	1
4-8	GB/T6170	锁紧螺母 M6 NUT M6	3	4-17	HK5S.12-4	操纵手柄密封圈垫圈 TILLER HANDLE SEAL WASHER	1
4-9	HK5S.12-9	油门转杆 ROD HANDLE	1				

5 齿轮箱部件

5 GEAR CASE




5 齿轮箱部件
5 GEAR CASE

序号 Ref No	图号 Part No	名称及规格 Description	数量 Q'ty	序号 Ref No	图号 Part No	名称及规格 Description	数量 Q'ty
5-1	HK5S.14-1 2	传动轴 DRIVE SHAFT	1	5-30	GB/T9074.14	六角螺栓组合 M6×16 BOLT M6×16	2
5-2	HK5S.13-1 4	水泵下盖油封 10×24×8 OIL SEAL 10×24×8	1	5-31	HK5S.16-7	螺旋桨挡片垫圈 PROPELLER BLOCK GASKET	1
5-3	HK5S.14-7	轴承垫圈 26.1×34.7×0.15 BEAR WASHER 26.4×34.7×0.15	2	5-32	HK5S.16-01	螺旋桨总成 PROPELLER	1
5-4	GB276	轴承 6300 BEARING 6300	1	5-33	GB/T96	大垫圈 10 BIG WASHER 10	1
5-5	HK5S.14-1 0	传动轴间隔套 DRIVE SHAFT SPACER	1	5-34	GB/T6178	六角开口槽螺母 M10 NUT 10	1
5-6	GB/T290	滚针球轴承 HK1412 BEARING HK1412	1	5-35	GB/T191	开口销 2.5×22 PIN COTTER 2.5×22	1
5-7	HK5S.14-1 1	滚针衬套 NEEDLE BUSH	1	5-36	HK5S.14-01	花键轴 SHAFT PROPELLER	1
5-8	HK5S.14-1	主动齿轮 PINION	1	5-37	HK5S.14-5	垫块 BLOCK	1
5-9	HK5S.16-1	齿轮箱 CASING LOWER	1	5-38	HK5S.14-6	换向挺柱 ROD PUSH	1
5-10	GB/T9074. 14	六角螺栓组合 M6×26 BOLT M6×26	1	5-39	HK5S.14-2	从动齿轮 GEAR	1
5-11	HK5S.11-1 0	密封座压板 SEAL SEAT PLATE	1	5-40	HK5S.14-4	主动齿轮垫圈 21×28×0.15 WASHER 21×28×0.15	1
5-12	HK5S.11-5	变档拉杆密封座 SHIFT ROD SEAL SEAT	1	5-41	GB276	轴承 6004 BEARING 6004	1
5-13	HK5S.11-1 2	O 型圈 20×2.4 “O”RING 20×2.4	1	5-42	GB819.2	十字槽沉头螺钉 M6×20 SCREW M6×20	1
5-14	GB/879.2	弹性圆柱销 3×12 SPRING PIN 3×12	1	5-43	HK5S.16-4	进水口盖 WATER INLET CAP	1
5-15	HK5S.11-4	变档拉杆 GEAR POLE	1	5-44	GB5781	螺栓 M8×34 BOLT M8×34	1
5-16	HK5S.11-6	变档拉杆头 SHIFT ROD HEAD	1	5-45	GB/T95	垫圈 8 WASHER 8	1
5-17	GB/879.2	弹性圆柱销 3×10 SPRING PIN 3×10	1	5-46	HK5S.13-5	进水管密封圈 WATER INLET PIPE SEAL RING	2
5-18	GB5781	螺栓 M6×45 BOLT M6×45	5	5-47	HK5S.13-13	水泵下盖密封垫 GASKET COVER WATER PUMP	1
5-19	HK5S.16-8	石棉垫 8×15×1.2 GASKET 8×15×1.2	4	5-48	HK5S.13-12	水泵下盖 COVER WATER PUMP	1
5-20	GB/T65	开槽圆柱头螺钉 M8×8 BOLT M6×16	2	5-49	HK5S.13-9	水泵隔板密封垫 GASKET PANEL WATER PUMP	1
5-21	HK5S.16-3	阳极块 ANODE	1	5-50	HK5S.13-8	水泵隔板 PANEL WATER PUMP	1
5-22	GB5781	螺栓 M6×16 BOLT M6×16	1	5-51	HK5S.13-10	水泵密封垫 GASKET WATER PUMP	1
5-23	HK5S.14-3	反向齿轮垫圈 15.2×19×1.8 COUNTER-GEAR WASHER 15.2×19×1.8	1	5-52	GB/119	圆柱销 2×11 PIN 2×11	1
5-24	HK5S.14-0 3	反向齿轮 COUNTER-GEAR	1	5-53	HK5S.13-11	水泵叶轮 IMPELLER	1
5-25	HK5S.16-6	O 型圈 54×3 “O”RING 54×3	1	5-54	HK5S.13-7	水泵碗 LINER PUMP CASE	1
5-26	GB276	轴承 6002 BEARING 6002	1	5-55	HK5S.13-6	水泵体 WATER PUMP	1
5-27	HK5S.16-5	双向油封 15×28×10 OIL SEAL 15×28×10	1	5-56	HK5S.13-4	水泵进水管 WATER INLET PIPE	1
5-28	HK5S.16-0 2	螺旋桨挡片 25×34×0.7 PROPELLER BLOCK 25×34×0.7	1	5-57	HK5S.13-3	出水管密封圈 WATER OUTLET PIPE SEAL RING	1
5-29	HK5S.16-2	齿轮箱盖 CAP LOWER CASING	1				

6 外包件、油壶部件

6 COWLING, FUEL



6 外包件、油壶部件
6 COWLING、FUEL

序号 Ref No	图号 Part No	名称及规格 Description	数量 Q'ty	序号 Ref No	图号 Part No	名称及规格 Description	数量 Q'ty
6-1	HK5S.18-1 3	拉手密封圈 HANDLEBAR JACKCT	1	6-22	HK5S.18-7	自锁拉杆护套 SELF LOCK ROD COVER	1
2-2	HK5S.18-0 1	外罩总成 UPPER APRON	1	6-23		放油孔密封盖 OIL OUTLET SEAL CAP	1
6-3	HK5S.18-1 4	外罩密封条 SHORT AIRPROOT BAR	1	6-24	HK5S.18-4	排水孔密封盖 DRAINAGE HOLE SEAL COVER	1
6-4		前整流器套 FORE-RECTIFIER BRUSH	1	6-25	GB/T955	波形弹性垫圈 15*20*0.5 SPRING WASHER 15*20*0.5	1
6-5		整流器 RECTIFIER	1	6-26	HK5S.18-1 2	合罩手柄爪 COVER HANDLE PAWL	1
6-6		后整流器套 REAR-RECTIFIER BRUSH	1	6-27	GB/T96	大垫圈 6 BIG WASHER 6	9
6-7		油箱支架 TANK SUPPORT	1	6-28	HK5S.18-9	合罩手柄 COVER HANDLE	1
6-8	HK5S.18-1	托盘 BRACKET TRAY	1	6-29	HK5S.18-1 1	合罩手柄密封垫 COVER HANDLE SWAL GASKET	1
6-9	GB819.2	十字槽沉头螺钉 M4×10 SCREW M4×10	2	6-30	HK5S.18-1 0	合罩手柄减磨套 COVER HANDLE ANTI-FRICTION BUSH	1
6-10	GB/T9074. 14	六角螺栓组合 M6×16 SCREW M6×16	4	6-31		油滤总成 OIL FILTER	1
6-11	159.05-03	燃油开关总成 OIL ON-OFF HANDGRIP SHAFT	1	6-42	154.05-9	油排气螺栓（154S 通用） EXHAUST BOLT	1
6-12	GB5782	螺栓 M6×12 BOLT M6×12	2	6-33		油箱支架减震套 TANK SUPPORT ASVORBER BUSH	3
6-13		油门线座 ACCELERATOR CABLE SEAT	1	6-34		内油箱总成 TANK FUEL	1
6-14	HK5S.18-3	小密封盖 SMALL SEAL CAP	3	6-35	GB/T6182	防松螺母 M6 NUT M6	5
6-15	GB5781	螺栓 M6×40 BOLT M6×40	1	6-36	159.05-1	内油箱盖减震圈 TANK FUEL CUSHION	1
6-16	HK5S.19-0 3	进油接头总成 OIL INLET ASSEMBLY	1	6-37	154.05-11	防掉板（154S 通用） DRAFT BAR	1
6-17	HK5S.19-1	进油接头护套 OIL INET COVER	1	6-38	154.05-7	油箱盖密封圈（154S 通用） FUEL CAP AIRPROOT RING	1
6-18		风门拉杆 KNOB CHOKE	1	6-39	154.05-10	内油箱盖（154S 通用） FUEL CAP	1
6-19	HK5S.18-5	风门手把密封套 CHOKE HANDLE GROMMET	1	6-40	154.05-8	排气螺栓密封圈（154S 通用） EXHAUST BOLT AIRPROOT RING	1
6-20	HK5S.12-1 6	风门手柄 CHOKE HAND	1	6-41	GB/T91	开口销 2×20 PIN COTTER 2×20	1
6-21	HK5S.18-2	大密封盖 BIG SEAL CAP	1	6-42	154.05-9	油排气螺栓（154S 通用） EXHAUST BOLT	1